



Capsule Polishing

For polishing and cleaning residual cortex from the capsular bag in preparation for insertion of the intraocular lens.


Soft Tip Soft tip for gentle polishing and provides atraumatic insertion and removal.




6023 Soft Tip Cannula
23G x 7/8 in (.60 x 22mm)
Angled 8mm from end
10mm sleeve

6025 Soft Tip Cannula
25G x 7/8 in (.50 x 22mm)
Angled 8mm from end
10mm sleeve




6027 Soft Tip Cannula
27G x 7/8 in (.40 x 22mm)
Angled 8mm from end
10mm sleeve





6427 Posterior Capsule Polisher - Engels
27G x 7/8 in (.40 x 22mm)
Curved, 23mm sleeve
Beveled down for polishing posterior capsule


Micro Etched Slightly roughened for gentle capsule polishing.




6121 Capsule Polisher - Kratz
21G x 7/8 in (.80 x 22mm) .4mm top port
Angled, 9mm from end; micro etched 3mm from end


6123 Capsule Polisher - Kratz
23G x 7/8 in (.60 x 22mm) .4mm top port
Angled, 9mm from end; micro etched 3mm from end



6221 Capsule Polisher
21G x 7/8 in (.80 x 22mm) Angled, 4mm from end;
micro etched 5mm from end

6423 Olive Tip Polisher
23G x 7/8 in (.60 x 22mm)
Angled, 10mm from end; micro etched olive shape tip is 1mm wide x 2mm long

6527 Olive Tip Capsule Polisher
27G x 7/8 in (.40 x 22mm) Curved; micro etched olive shape tip is 1mm wide x 2mm long

